

C-1004

Crate Innovations 602 Spacer

This angled spacer is designed to be used in one position to flatten the carb on a 602 crate engine.

- The high side towards front of engine
- The center divider towards the intake

DO NOT attempt to run it with center divider towards the carb.

Use it as marked and instructed.

- Tighten the carb evenly and do not over tighten.
- Some base plates may require mounting holes to be slightly enlarged
- Billet Base Plate is recommended.

Note: This spacer is NOT legal in all sanctions.
Check local rules before using.