

Crate Innovations

C-1001-*PLUS*

- The car must be raised on the left side to level the carburetor before setting float levels.
- ONLY 750 CFM or smaller carburetor should be used
- Carburetor should have billet aluminum base plate
- Some base plates may require mounting holes to be slightly enlarged
- **ALWAYS** check for adequate clearance between throttle plates and spacer
- ALSO check clearance at any linkage areas
Evenly tighten carb and
DO NOT Overtighten
Improper installation can cause damage to the carburetor and throttle linkage