

# **Crate Innovations**

## **CII-1001-*PLUS***

- The car must be raised on the left side to level the carburetor before setting float levels.
- ONLY 750 CFM or smaller carburetor should be used
- Carburetor should have billet aluminum base plate
- **ALWAYS** check for adequate clearance between throttle plates and spacer
- ALSO check clearance at any linkage areas

**Evenly tighten carb and**  
**DO NOT Overtighten**

Improper installation can cause damage to the carburetor and throttle linkage